





1. Distance Measurement




Choose a flat and solid ground, and measure the distance between the two columns.

2. Install The Base




Install 2 bases and insert four expansion screws to fix them.

3. Install The Column




Put the column into the base and fix it with 6 screws.

4. Fix The Bottom Cover




Insert the corner braces into the notches at the ends of the bottom cover, and secure them to the columns with screws.

5. Install Fence Panels




Make the narrow side of the fence panel face up and snap the other side into the bottom cover.

6. Install All Fence Panels




Insert all 9 fence panels from the recesses of the column and make each panel tight to each other.

7. Fix The Top Cover



Place the corner braces into the top cover recess (opposite to the way the bottom cover is inserted) and secure them to the column with screws.

8. Finish Installation



Buckle the cap on the top of the column to complete the installation. Other fences continue to be installed in this order.