


# **Fence Installation Steps**



## Installation Instructions

### 11 DISTANCE MEASUREMENT

Choose a flat and solid ground, and measure the distance(6 FT) between two posts.

### 2 INSTALL THE BASE

Install the base and insert 4 expansion screws to fix them.



### **3 INSTALL THE POSTS**

Place the post in the base and secure it with 12 screws. If it is a embedded fence, the post is directly inserted into the concrete, the distance is 60cm. The remaining steps are the same as the ordinary fence installation (the sealing strips on both sides of the column can be removed, replaced and re-inserted).



### 4 FIX THE BOTTOM COVER

Insert the corner braces into the groove at the ends of the bottom cover, and secure them to the posts with screws.



FULLY ENCLOSED FENCE, please follow the steps in 5-1 and 6-1

### 5-1 INSTALL THE FIRST FENCE PANEL

Make the narrow side of the fence panel face up and snap the other side into the bottom cover.



SEMI-ENCLOSED FENCE, please follow the steps in 5-2 and 6-2

### 5-2 INSTALL THE FIRST FENCE PANEL

Snap the wider fence panel into the bottom cover with the narrow side facing down, and the other side facing up.



OPEN STYLE FENCE, please follow the steps in 5-3 and 6-3.

### 5-3 INSTALL THE FIRST FENCE PANEL

Snap the either side of the fence panel into the bottom cover, and put the spacer on the other side of the panel.



### **Installation Instructions**

### 6-1 INSTALL ALL FENCE PANELS

Place the all panels in sequence and fasten them tightly to each other.




### 6-2 INSTALL ALL FENCE PANELS

Place the other 6 wider panels in order. Then put the spacer on top side of the panel, and then a narrower panel. The other 2 narrower panels are installed accordingly.



### 6-3 INSTALL ALL FENCE PANELS

Place the other 13 panels in sequence and fasten them tightly to each other.



### 7 INSTALL THE TOP COVER

Place the corner braces into the top cover groove and secure them to the posts with screws.




### **8** FINISH INSTALLATION

Buckle the cap on the top of the post to complete the installation. Other fences continue to be installed in this order.




### Accessories display











Material: iron
Shape: Rectangle
Suitable for all sizes of post



Material: Aluminium allo Fit 75\*75 mm-size post



Material: iron
Size:140\*140mm

## Angle column

The fence can be installed in a curved area

